

## HPE MyRoom/VRG HMT-1 Commands

---

### GENERAL

**Navigate Back** Goes back to the previous screen.

**Close Dialog** Closes any popup dialog.

**Close VRG** Quit out of VRG application.

### ROOM LIST VIEW

To enter into a specific room from the list of displayed rooms, say the name of the room.

### ROOM – GENERAL

**Toggle Microphone** Turns microphone on/off.

**Toggle Speaker** Turns speaker on/off.

**Close Room** Closes current room and returns to room list view.

**Next View** Brings the next thumbnail view to full-screen mode.

**Generate Key** Creates a room key for new participants to enter.

### ROOM – CAMERA

**Toggle Camera** Turns camera on/off.

**Toggle Resolution** Toggles resolution low/high.

**Take Snapshot** Takes the camera snapshot.

**Toggle Flash** Turns flash on/off.

**Zoom level 1** Displays in normal size.

**Zoom level 2** Displays in 2x size.

**Zoom level 3** Displays in 3x size.

**Zoom level 4** Displays in 4x size.

### ROOM – SETTINGS

**Toggle Ringtone** Changes the ringtone for incoming chat messages.

**Toggle Network Health** Turns health settings on/off.

**Toggle Speaker Phone** Turns speaker phone on/off.

**Toggle Resolution** Toggles resolution low/high.

### ABOUT DIALOG

**Show About** Shows about dialog.

**Close Dialog** Closes about dialog.

### SETTINGS DIALOG

**Open Settings** Opens the settings dialog.

**Play Chat Sound** Toggles ringtone.

**Speakerphone** Turns speakerphone on/off.

**Show Network Health** Turns health settings on/off.

**Enable Large Video Resolution** Toggles resolution low/high.

**Translate Chat** Toggles text translation.

**Close Dialog** Closes settings dialog.

### CHAT

**Toggle Chat** Brings up or removes chat view.

**Toggle Translate** Turns text translation on/off.

### ROOM – TASK LIST

**Previous Step** Moves to previous step.

**Next Step** Moves to next step.

## RealWear HMT-1 Commands

---

### GLOBAL COMMANDS

**Navigate Home** Navigates to Home Screen.

**Navigate Back** Navigates to previous screen.

**My Controls** Navigates to system control panel.

**Mute Microphone** Mutes the microphone temporarily.

**My Notifications** Opens Notification section.

**Recent Applications** Opens Applications running in background.

**Show Help** Displays pop-up window with the help for commands.

**Page Up** Navigates one page up.

**Page Down** Navigates one page down.

**Page Left** Navigates one page left.

**Page Right** Navigates one page right.

### CAMERA FUNCTIONS

**Zoom Level 1-5** Zooms the camera view.

**Take Photo** Takes a photo and saves it to the My Photos folder as JPEG file.

**Start Recording** Starts recording a video.

**Stop Recording** Stops the ongoing video recording.

**Auto focus / Manual focus** Sets the camera to auto focus or manual focus mode. By default, the camera is set to auto focus mode. To toggle to manual focus say **Manual focus**. If Manual focus is ON, a four corner bracket with an M is displayed in the lower right corner of the display screen, to indicate that the camera is in manual focus mode.

**Flashlight On/Off** Switches On/Off flashlight.

### VIRTUAL HANDS-FREE KEYBOARD

**Accept** Accepts the entered information.

**Spacebar** Inserts a single space.

**Backspace** Deletes the last character.

**Clear Text** Clears the text in the Input box.

**Caps On** Uses capital letter.

**Caps Off** Uses lowercase letter.

**Dictation** Activates dictation and enters text with speech recognition.

**Scan Code** Scans QR code.

**Zoom level 1-5** Sets the zoom level.

**All Symbols** Switches to Symbol keyboard.

**Switch Mode** Toggles between single entry and multiple alphabets.

**Letter [followed by the letter]**. E.g. to type XYZ, say Letter XYZ.

### DOCUMENT NAVIGATION

**Zoom Level 1-5** Zooms the document view size.

**Freeze Document** Prevents the document from scrolling.

**Control Document** Unfreezes and enables document scrolling.

**Go to page 1, 2...** Scrolls to the specified page.

**Next Page/Previous Page** Scrolls to next/previous page.

**My Bookmarks** Displays the bookmarks currently saved in the device for the open document.

**Add Bookmark** Adds a desired page as a bookmark for easier access.

**Delete Bookmark** Deletes the bookmark set to a desired page. To delete a bookmark, you must go to that page and say **Delete bookmark**.